

# Debug

## GDB

- [GDB Quick Reference](#) (pdf)
- my .gdbinit

```
set print pretty on
set listsize 32
set breakpoint pending on
set tcp connect-timeout 4

define hook-quit
    set confirm off
end

# signals
handle all print
handle SIG32 nostop noprint pass

# set sysroot <build-path/sysroot-dir>
# set solib-search-path bla:and:bla
# cd <build-path>
# file ./<app>
target remote 192.168.11.10:2345

# C++ exceptions
# GCC: break __cxa_throw
# catch throw
# catch throw std::*
catch throw std::out_of_range

# breakpoints
b main
b abort
b std::terminate

c
```

## Lauterbach TRACE32

### Links

- [Lauterbach Documentation](#)
- [PRACTICE Reference Card](#)
- [Linux Debugging Reference Card](#)

## Commands

- start of debugger

```
t32m* [-c <conf> [arg]] [-s <script> [arg]]
```

## Files

- ~/t32.cmm: start-up script, searched in PATH

## Examples

- start-up script

```
;RADIX Hex

Break.Set \\vmlinux\traps\die /Onchip
Break.Set __do_user_fault /Onchip

MENU.ReProgram
(
  ADD
  TOOLBAR
  (
    TOOLITEM "Start <app> debugging" "do
~~/demo/arm/kernel/linux/linux-3.x/app_debug.cmm <app> /dialog"
  [

    BBB BBB BBB
    B B B B B B
    B B B B B B
    BBB BBB BBB
    B B B B
    B B B B
    B B B B

  ]
    TOOLITEM "Start <other> debugging" ":pgo" "do
~~/demo/arm/kernel/linux/linux-3.x/app_debug.cmm <other> /dialog"
    SEPARATOR
  )
)

TOOLBAR ON
STATUSBAR ON
FramePOS 0.0 3.75 234. 56.
WinPAGE.RESet
```

```
WinPAGE.Create P000
WinCLEAR

WinPOS 0.25 32.875 148. 11. 32. 1. W001
WinTABS 13. 0. 20. 0. 0. 20. 0.
ws.BREAK.LIST

WinPOS 0.0 0.0 148. 41. 22. 1. W000
WinTABS 10. 10. 25. 62.
ws.DATA.LIST

WinPOS 114.13 33.0 156. 11. 31. 1. W003
WinTABS 24.
ws.SYMBOL.AUToload.LIST

WinPOS 164.63 0.0 67. 29. 5. 0. W002
wl.Frame

WinPAGE.select P000

ENDDO
```

From:

<https://wiki.rho62.de/> - rho62 Wiki

Permanent link:

<https://wiki.rho62.de/doku.php?id=development:tools:debug:start>

Last update: **2023/10/21 18:56**

